
VR REMOTE CONTROLLER MODEL 1003315

KEV:UI

2017-4-20



OPERATIG RATIO DISTRIBUTION

I)THE BOOT: LONG PRESS THE POWER ON/OFF BUTTOM 3SEC, THE LED LIGHT INTO THE SLOW BLUE COLOR FLASH. 2)SEARCH SLOW LED LIGHTS FLASHING.

3)THE CONNECTION IS SUCCESSFUL THE LED LIGHT WENT OUT.

4) SYSTEM CHOICE: AUTOMATIC IDENTIFICATION android AND iOS SYSTEM,

5)SWITCH MODE: AFTER CONNECTION HOLD @BUTTON CLICK ON THE CORRESPONDING A-B-C-D KEY, YOU CAN SWITCH

TO CORRESPONDING MODE.

SWTHCH TO THE PRESS A-B-C-D KEY LED LIGHT PUT OUT.

6)SHUT DOWN:SEACH WITHOUT AND MATCHING CONNECTION 3MINUTES ANTOMATIC SHUT DOWN,CONNECTION STATUS, WITH OUT AND OPERATION AUTOMATIC SHUT DOWN 10MINUTES.

7)LONG SHUT DOWN:PRESS THE POWER BUTTON FOR 3SEC, UNDER THE LED FLASH 10 TO TURN OFF.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.